Master Blend # 6 Disinfectant

M2260065

A super concentrated quaternary ammonia detergent and disinfectant. The half gallon containers are designed to be used with the Master Blend Dispensing System and color coded quart bottle system. Master Blend features SafeLink Adaptive Closed-Loop[™] Technology. It prevents leaks and is safer for employees and the environment. Economical and easy to use.





WALL MOUNT UNIT #HYDSP3066



5 PRODUCT RACK #ACP627

STANDARD FOAMER #DEMA52339

PREMIUM FOAMER #DEMA52336



Where To Use

HospitalsAthletic FacilitiesSchoolsNursing HomesOfficesRestaurants

Rest rooms Telephones Bars Health Care Facilities Garbage Can & Storage Areas Floors, Walls, Tables, etc.

Dilutions

1-2 oz.. per gallon depending on soil load.

Directions

Master Blend Disinfectant #6 is designed to be diluted at 1-2 oz. per gallon through the Simoniz Master Blend Dilution Systems. The Master Blend systems are preset for a 2 oz. per gallon dilution for filling quarts and 1 oz. per gallon (wall mount unit) for the bucket fill. If a different dilution is desired, please see the instructions with the dispenser to determine the correct metering tip. (Portable Master Blend units are preset at 2 oz. per gallon). Simply attach the half gallon to the dispenser via the cap at the end of the draw tube (wall mount) or attach the portable unit directly on to the half gallon and fill either quarts or mop buckets. If using this product with another dispenser, use the appropriate tip for the desired dilution. (Please note, in order to use Master Blend products with other dispensers, part number C38CS4W must be attached on the pickup tube.)

Preclean extremely dirty areas and remove any obvious gross dirt. Dilute, based on the table above. Depending on the application, apply diluted solution with a mop, cloth, sponge or trigger sprayer. Wet all surfaces thoroughly and allow to remain wet for 10 minutes. Remove excess liquid. Prepare a fresh solution for each use. **To Disinfect toilet bowls** – Flush toilet, add 1 oz.. of product directly into the bowl water. Swab bowl completely, including under the rim. Let stand 10 minutes, then flush. **HIV-1** (**Aids Virus**) – The areas to be disinfected must be pre-cleaned of all blood and body fluids. Please read label instructions for use in HIV-1 disinfection. *It is a violation of federal law to use this product in a manner inconsistent with its labeling.*

Technical Specifications

COLOR:	
FORM:	.Liquid
SCENT:	
pH:	
FLASH POINT:	.None
VISCOSITY:	. Water Thin
FOAM:	.Low
TYPE:	. Super Concentrate
	Quaternary Ammonia
	Detergent/Disinfectant



201 Boston Turnpike, Bolton, CT 06043-7203 800-227-5536 • 860-646-0172 • FAX 860-645-6070