

A one-step phosphate-free quaternary detergent/disinfectant cleaner, deodorizer and virucide. Effective against *Pseudomonas aeruginosa*, *Staphylococcus aureus* and *Salmonella choleraesuis*, *Staphylococcus aureus* - Methicillin Resistant (MRSA), *Enterococcus faecalis* - Vancomycin Resistant (VRE, Hepatitis B Virus (HBV) and Human Immunodeficiency Virus Type 1 (HIV-1).



### Where To Use

Hospitals	Health Clubs	Rest rooms	Medical Offices
Schools	Nursing Homes	Telephones	Health Care Facilities
Offices	Restaurants	Bars	Garbage Can & Storage Areas
Dental Offices	Hotels	Kitchens	Floors, Wells, Tables, etc.

### Dilution

1/128 (1 oz./gal)

### Directions

It is in violation of Federal Law to use this product in a manner inconsistent with its labeling. Pre-clean extremely dirty areas and remove any obvious gross dirt. Dilute, based on table above. Depending on the application, apply the solution with a mop, cloth, sponge or trigger sprayer. Wet all surfaces thoroughly and allow to remain wet for 10 minutes. Remove excess liquid. Prepare a fresh solution for each use. **To Disinfect toilet bowls** – Flush toilet, add 1 oz. of Select directly into the bowl water. Swab bowl completely, including under the rim. Let stand 10 minutes, then flush. **HIV-1 (Aids Virus)** – The areas to be disinfected must be pre-cleaned of all blood and body fluids. To kill Hepatitis B Virus (HBV) add 1 oz. per gallon of water on hard, nonporous, inanimate environmental surface for a 10 minute contact. To kill Human Immunodeficiency Virus Type, the contact time should be 30 seconds.

### Technical Specifications

COLOR: .....Transparent green	VISCOSITY: ..... Water thin
FORM: .....Liquid	STORAGE(Unopened):..... 1 Year @R.T.
SCENT: .....Lemon	BIODEGRADABLE: ..... Yes
pH: .....12.0	WEIGHT/GAL: ..... 8.8
FLASH POINT: .....None	SHIPPING CLASS: ..... None
FOAM: .....Low	PACKAGING: ..... 4x1,5 gal, 55 gal
TYPE: 1 oz./gal, Quaternary Ammonium Disinfectant	
EPA Reg No. 6836-57-18305	

