TROUBLESHOOTING CHART:

Problem	Cause	a. Open water supply b. Install regulator if flowing water pressure exceeds 85 PSI c. Disconnect inlet water line and clean strainer d. Install valve parts kit	
1. No discharge	a. No water b. Excessive water pressure c. Clogged water inlet strainer d. Magnetic valve not functioning		
2. No concentrate draw	a. Low water pressure b. Concentrate container empty c. Discharge tube and/or flooding ring not in place d. Clogged water inlet strainer	a. Minimum 25 PSI (with water running) required to operate unit properly b. Replace with full container c. Push tube firmly onto eductor discharge hose barb, or replace tube if it doesn't have a flooding ring d. Disconnect inlet water line and clean strainer	
3. Foaming in discharge	a. Concentrate container malfunctioning b. Air leak in pick-up assembly c. Poor vent seal (#9 on parts diagram)	a. Replace with new concentrate container b. Replace pick up assembly with kit c. Replace vent seal	
4. Failure of unit to turn off	a. Excessive water pressureb. Magnet doesn't fully returnc. Water valve parts dirty or defective	 a. Install regulator if pressure (with water flowing) exceeds 85 PSI b. Make sure magnet moves freely Replace spring if short or weak c. Clean or replace with valve parts kit 	



90087930 Rev. A 4/09



ALWAYS

ALWAYS

ATTACH

KFFP

Blend Rite Wall Mount **Dispenser**

Package Should Contain:

- Proportioner unit .
 Discharge tube(s).
 Hose hook --3.5 GPM eductor only.
- 4. Mounting hardware.
- 5. Water inlet hose, 3/8" x 6'.
- 6. Instruction sheet.

THANK YOU FOR YOUR INTEREST IN OUR PRODUCTS

equipment clean to maintain proper operation.

only to tap water outlets (85 PSI maximum).

	_
WEAR	protective clothing and eyewear when dispensing chemicals or other materials.
ALWAYS	observe safety and handling instructions of the chemical manufacturers.
AL WAYC	direct discharge away from you or other persons or into approved containers

dispense cleaners and chemicals in accordance with manufacturer's instructions. Exercise CAUTION when maintaining your equipment.

WEAR	protective clothing and eyewear when working in the vicinity of all chemicals, filling or
	emptying equipment or changing metering tips.


re-assemble equipment according to instruction procedures. Be sure all components are firmly screwed or latched into position.

If the unit is used to fill a sink or the discharge hose can be placed into a sink, the unit NOTE must be mounted so that the bottom of the cabinet is above the overflow rim of the sink.

Installation & Operation:



ing tabs under cover.



1. Remove cover by press- 2a. Remove unit mounting bracket from back of dispenser by depressing the tabs.





Drill holes for four wall anchors with a 5/16" drill bit. Use the mounting bracket as a template for proper spacing of the mounting screws. Install anchors, and then screw into anchors.



4. Place dispenser on bracket.



5. Secure dispenser to bracket by sliding locking bar through back of unit. Replace cover.



6. Attach short discharge tube on 1 GPM (grey) eductor, then attach longer discharge tube on 3.5 GPM (yellow) eductor.



7. Place hose hook on end of 3.5 GPM discharge tube. Hang on dispenser when not in use.

Continued..Next Page

Installation & Operation Continued:



8. Connect water supply hose of at least 3/8" ID to water inlet swivel. Min. 25 PSI pressure is required for proper operation. Connect opposite end of hose to water supply. Turn water supply on.



9. Insert product container into shroud until it locks into place.





10a. Push button to start flow of desired concentrate solution; release button to stop flow of solution.
 To lock the High Flow button in the "on" position: press button until it "locks" into place.
 10b. To unlock, press button release lever on left side of cabinet.





11. To remove chemical concentrate container, place hand securely under the empty product, slide release lever to the right and pull concentrate container out.

Key	Part No. I	Description
1	238100	Strainer washer
2	10082801	Swivel stem (molded)
3	10082830	Swivel collar (molded))
4	10075925	Pipe plug
5	10075980	Valve parts kit
		a. diaphragm
		b. armature
		c. spring
		d. valve bonnet
6	10079010	Spring
7	10079000	
8a		1.0 GPM flow control kit
b		3.5 GPM flow control kit
9a	10089941	Eductor lock left
b		Eductor lock right
10	10089938	Vent seal
11	10089983	- 3
12a	290SMP	1.0 GPM eductor assembly
b	291SMP	3.5GPM eductor assembly
13	10089927	
		n eductor assembly
14a		Tubing replacement kit (1.0 GPM)
b		Tubing replacement kit (3.5 GPM)
15a	90081017	1.0 GPM discharge tube
		with flooding ring (10")
b	90080288	3.5 GPM discharge tube
		with flooding ring (6')
16	10080730	9 - ,
17		Cabinet front
18a		Button, Bottle
b		Button, Bucket
19	10090042	5
20		Locking button release
21	10089931	3
22	10089976	Locking bar

NOT SHOWN:

10091920 Water inlet hose, 3/8" X 6'

